



kitsound.co.uk



Do not dispose of Lithium Polymer
batteries with general waste.
Please return it to battery recycling
collection point

JB.2742 / Made in China. © KitSound™ 2013
Christchurch, Dorset. BH23 4FL

ks™

KITSOUND

POCKETBOOM WIRELESS SPEAKER

MANUAL







We are craftspeople. We are
musicians. We are KitSound™

And we all commit ourselves to
achieving one shared goal: Bringing
people closer to their music. By truly
understanding music we stay true to
its craft. Pure, rich, incredible sound.
We'll settle for nothing less.

At KS we believe your music deserves to be showcased on great quality products that don't cost the earth. We might not all share the same taste in music (the ferocious disputes on music forums prove that), but whether it's Irish folk, death metal or any number of obscure genres which seem to be multiplying by the minute, the artists responsible for connecting with you through their craft have bared their souls to do so. And we think that's worth celebrating.



1. Hands-free button
2. ON/OFF switch
3. Microphone
4. Aux-in socket
5. Bluetooth pairing indicator light
6. Mini USB Port
7. Speaker
8. Radiator



Charging the battery for the first time

The unit has a built-in rechargeable lithium battery. Connect one end of the power cable to the mini USB port of the main unit and connect the other end to your PC. The battery will start charging.

Note:

- It takes approx 1.5 hours to fully charge the battery
- A fully charged unit has approximately 3 hours of playback time.

Bluetooth pairing

1. Switch the power button to the ON position.
The Bluetooth indicator light will flash blue (quickly).
2. When you search for the speaker with your Bluetooth device, you should see "PocketBoom".
Enter the password '0000' if requested.
3. When pairing is successful, the Bluetooth indicator light will flash slowly.
4. If no pairing occurs within 5 minutes, the unit will automatically enter standby mode.

Hands-free

There is a hands-free button on the top of the unit. When your phone is paired with the unit, you can press and hold the hands-free button to call back the last answered phone number. During a phone conversation, you can short press the hands-free button to discontinue the conversation. Additionally, you can short press the hands-free button to answer an incoming call.

Aux-in

Use a 3.5 mm aux-in cable (not supplied) to connect your Bluetooth speaker through the aux-in socket at the bottom of the unit.

Note:

When you plug the aux-in cable into the aux-in socket, the current Bluetooth connection will disconnect.

When you unplug the aux-in cable, the Bluetooth connection will resume.

Care and maintenance

Wipe the unit with a soft dry dust cloth. Do not use any wax, polish sprays or abrasive cleaners on it.

Caution:

Never allow any water or other liquids to get inside the unit while cleaning.

Specifications

- Bluetooth: v2.1
- Play time: up to 3 hours (at 80% volume)
- Frequency response: 100 Hz – 15 kHz
- Battery type: rechargeable
- Aux-in: 3.5 mm

Troubleshooting

We hope you've now got all the information you need to get started, but if you're having problems with anything, please feel free to contact us at: support@kitsound.co.uk